

Tire and Automotive - Standard Upgrades Options



TGIS Upgrades

Quote Letter and Line Item	Title / Description
Tire0002-00	TGIS-SL on D70
Tire0002-01	TGIS-SL AkroSCAN™ Sheet of Light System (11" or 13" Transport)
Tire0002-02	TGIS to TQC-PC Integration Kit (required for TQC-PC equipped D70)
Tire0002-03	Shutter Option for the Full-Motion TGIS/SL AkroSCAN System
Tire0002-04	Position Calibration and Measurement Verification Wheel
Tire0002-05	D70 Nose Cone Adapter (for Verification Wheel)
Tire0003-00	TGIS-SL on ASTEC
Tire0003-01	TGIS-SL16 AkroSCAN™ ASTEC (B, C, D and E) (Cabinet)
Tire0003-02	TGIS-SL16 AkroSCAN™ ASTEC F, ASTEC FX (Integrated)
Tire0003-03	Shutter Option for the Full-Motion TGIS/SL AkroSCAN System
Tire0003-04	Position Calibration and Measurement Verification Wheel
Tire0004-00	TGIS-SL on AkroDYNE and AkroDYNE FX (AB and SE)
Tire0004-01	TGIS-SL AkroSCAN™ AkroDYNE (cabinet)
Tire0004-02	TGIS-SL AkroSCAN™ AkroDYNE, AkroDYNE FX (integrated)
Tire0004-03	Shutter Option for the Full-Motion TGIS/SL AkroSCAN System
Tire0004-04	Position Calibration and Measurement Verification Wheel (AkroDYNE, AkroDYNE FX)
Tire0004-05	Position Calibration and Measurement Verification Wheel (AkroDYNE w/ ARC, AkroDYNE FX w/ ARC)
Tire0006-00	TGIS-SL HSSI to AkroSCAN
Tire0006-01	Three (3) sensor TGIS-SL HSSI to AkroSCAN™ Upgrade
Tire0006-02	Three (3) sensor TGIS-NM HSSI to AkroSCAN™ Upgrade
Tire0006-03	Shutter Option for the Full-Motion TGIS/SL AkroSCAN System
Tire0006-04	Position Calibration and Measurement Verification Wheel (AkroDYNE, AkroDYNE FX)
Tire0006-05	Position Calibration and Measurement Verification Wheel (AkroDYNE w/ ARC, AkroDYNE FX w/ ARC)
Tire0006-06	Position Calibration and Measurement Verification Wheel (ASTEC / D70)
Tire0006-07	D70 Nose Cone Adapter (for Verification Wheel)